


CAPTAIN

» INSTRUCTIONS OF USE



X Do not use as a step ladder

INDOOR USE ONLY



RIGHT INNER LEVER
To adjust seat height

RIGHT KNOB
To adjust weight tension

LEFT KNOB
To adjust seat and
back angle

LEFT INNER LEVER
To adjust seat depth
(Seat slider)

700MM ALUMINIUM 5 STAR BASE WITH CASTORS

Use soft tyred castors for tiles
Use hard tyred castors for carpet

- » Vacuum regular
- » Regularly adjust mechanism angle
- » Regularly adjust gas height
- » All warranty claims to be forwarded to place of purchase
- » Warranty covers components and workmanship only
- » Damage or wear and tear not covered by warranty
- » Misuse or abuse will not be covered under warranty